Product information

Bike Brake and Chain Cleaner



Description

Cleaner with specially selected combination of solvents. For the rapid and effective cleaning and degreasing chains and disk brakes on bicycles. Particularly effective on oily and greasy dirt.

Properties

- removes oil and grease-based contaminants
- leaves no residues
- high proportion of active components
- optimum penetration capacity

Technical data

Color / appearance colourless Flash point < 21 °C

Base solvent-mixture, acetone-

free

Form liquid, aerosol

Propellant CO2
Shelf life in original 30 Monate

sealed container

Areas of application

For cleaning and degreasing chains and disk brakes on bicycles. Also suitable for e-bikes.

Comment

Avoid direct contact with painted surfaces!

Do not lay rubber components in a container with cleaning fluid to clean them as they may be attacked.

Application

Spray generously over drive chain and catch excess fluid. Leave to dry for 10 minutes. Then treat with chain oil or chain spray.

Spray generously over disk brake system and catch excess fluid. Leave to dry for 10 minutes.

Available pack sizes

200 ml Can aerosol 20602

D-GB-I

200 ml Can aerosol 20717

GB-DK-FIN-N-S

400 ml Can aerosol 6054

D-GB-E-F-I

Our information is based on thorough research and may be considered reliable, although not



legally binding.

Phone: +49 (0)731/1420-0 Fax: +49 (0)731/1420-82 e-mail: info@liqui-moly.de